
Assembly Instructions For

OL6800 (E) 11/08



IMPORTANT TURN OFF THE POWER AT THE MAIN FUSE OR **CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION**

Carefully unpack and identify all parts before assembly. Bulb not included.

- I. Install finial by screwing onto top cover.
- 2. Follow enclosed supplement installation instructions for electrical and fixture installation onto house outlet box. If you do not have an outlet box at desired location to attach the fixture than hire a qualified electrician to create one.
- 3. Install bulb (not included). See relamping label located near socket area for type and maximum allowed wattage.

