



**IMPORTANT: TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION**

Carefully unpack and identify all parts before assembly.  
Bulb is not included.

## 1. STEM HUNG INSTALLATION:

A. Choose desired installation height from any combination of stems provided.  
NOTE: Additional stems can be purchased to increase installation height. Do not add more stems than will allow 6" (15cm) of fixture wires above canopy. Thread fixture wires through each stems to be used. Screw stems together until secure. Screw stem assembly into top of fixture until secure.

NOTE: This fixture can be installed without any stems for direct mount onto canopy.

B. Screw swivel securely onto top end of stem assembly (or top end of fixture for without stem installation).

2. Follow enclosed **"Multiple Standard Installation Instructions"** for electrical and fixture installation onto ceiling junction box.

4. Install glass shade onto fitters by fastening with two plastic washer and screws.  
**IMPORTANT:** Do not over tighten.

5. Install bulbs (not included). Use 75 Watt maximum of mini-can base halogen bulbs.  
**IMPORTANT:** Do not touch glass surface of halogen bulb with bare fingers. Use a clean and dry cloth or paper to handle them.

6. Install protective glass dome by snapping onto clip located next to sockets.