#### Q U O I Z E L 6 CORPORATE PARKWAY GOOSE CREEK, SC. 29445 www. quoizel. com

Quoizel, Inc. 6 Corporate Parkway Goose Creek, SC 29445

Customer Service Phone 631.273.2700 Fax 631.231.7102 www.quoizel.com

# Assembly Instruction Sheet #IS-CKDG1482T For Style CKDG1482T

Tools Required: None

**Bulb Recommended:** (1) Medium Base 100W Maximum

Estimated Assembly Time: 15-20 minutes

**Preparation:** Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.



### **Warnings and Cautions**


Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.

## **Package Contents**


Part	Description	Quantity
Α	Finial	1 pc.
В	Shade	1 pc.
С	Harp	1 pc.
D	Fixture Body	1 pc.



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700 or visit us on-line at www.quoizel.com

August 2012




Q U O Z E L
6 CORPORATE PARKWAY
GOOSE CREEK, SC. 29445
www. quoizel. com

# Assembly Instruction Sheet #IS-CKDG1482T For Style CKDG1482T


### STEP 1 - Install Harp

A. Locate the Harp (C) by pressing the ends of the Harp (C) into the Harp Clips on the top of Base (D).



### STEP 2 - Assemble Shade


A. Place Shade (B) over the top end of the Harp (C). Secure by thread the Finial (A) onto the Harp (C). Hand tighten until snug.



#### STEP 3 - Install Bulb

- A. This fixture uses standard bulbs with medium screw bases. Maximum 100 watts.
- B. Insert bulb and screw snugly into place.

Your fixture is now assembled and ready to use. Enjoy!



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com

© 2012 Quoizel Inc.

August 2012