



American by Design™

LIGHTING
BY QUOIZEL

Quoizel, Inc.

6 Corporate Parkway
Goose Creek, SC
29445

Customer Service

Phone 631.273.2700

Fax 631.231.7102

www.quoizel.com

Assembly Instruction Sheet #IS-LX6516H For Style LX6516H

Tools Required: None

Bulb Recommended: (1) Medium Base 60W Maximum

Estimated Assembly Time: 15-20 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.



Warnings and Cautions


Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.

Package Contents

Part	Description	Quantity
A	Harp	1 pc.
B	Base	1 pc.
C	Finial	1 pc.
D	Shade	1 pc.





Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700
or visit us on-line at www.quoizel.com

LX6516H

FINISH: BURNISHED BRASS



(1) 60W Medium
Base Bulb
(Not Supplied)

NO.	PART NUMBER	REPLACEMENT PART DESCRIPTION	REQ.
1	CL595IVG	COLUMN PORCELAIN IVRY W/GOLDEN #226-BK2	1
2	P1174FIH	FINIAL BURNISHED BRASS WITH IVORY PORCELAIN	1
3	S792WH	SHADE GLTALBSTR 4.5" x 8.5" x 8"	1
4	P568TLH	TASSEL BURNISHED BRASS W/BEAD CHAIN	1



American by Design™

LIGHTING
BY QUOIZEL

Assembly Instruction Sheet #IS-LX6516H For Style LX6516H

STEP 1 – Install Harp

- A. Install the Harp (A) by pressing the ends of the Harp (A) into the Harp Clips as shown.




Figure 1

STEP 2 – Assemble Shade

- A. Place the Shade (D) over the top end of the Harp (A) and secure with the Finial (C). Hand tighten until snug.




Figure 2

STEP 3 – Install Bulb

- A. This fixture uses standard bulb with medium screw base. Maximum 60 watts.
B. Insert bulb and screw snugly into place.

Your fixture is now assembled and ready to use. Enjoy!




Figure 3

Thank you for purchasing a Quoizel product.
Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700
or visit us on-line at www.quoizel.com