

Quoizel, Inc. 6 Corporate Parkway Goose Creek, SC 29445

Customer Service Phone 631.273.2700 Fax 631.231.7102 www.quoizel.com

Assembly Instruction Sheet #IS-MCRU2820HA For Style MCRU2820HA

Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.

Bulb Recommended: (4) Medium Base 100W Maximum

Estimated Assembly Time: 20-30 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.



Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.


These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.

Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700 or visit us on-line at www.quoizel.com

© 2011 Quoizel Inc. November 2011




NO.	PART NUMBER	REPLACEMENT PART DESCRIPTION	REQ.	
1	M2272CHHA	CHAIN HAZEL BRNZ 3.8MM X4'	1	
2	J1164FIHA	FINIAL HAZEL BRONZE .5"H	1	
3	9488KIT	MTG HDW/CNPY HAZEL BRNZ 5"SQ	1	
4	S1326MC	SHADE MICA 4"SQ X 20"SQ X 8.5"	1	
2of8				



Package Contents

Part	Description	Quantity
А	Crossbar	1 pc.
В	Nipple	1 pc.
С	Lock Washer	2 pcs.
D	Hex Nut	2 pcs.
Е	Canopy Chain Loop	1 pc.
F	Canopy Lock Ring	1 pc.
G	Fixture Chain	1 pc.
Н	Nipple with Hex Nut	1 pc.
I	Spacer Tube	1 pc.
J	Check Ring	1 pc.
K	Сар	1 pc.
L	Finial	1 pc.
М	Ceiling Canopy	1 pc.
N	Fixture Loop	1 pc.
0	Shade	1 pc.
Р	Fixture Body	1 pc.
Q	Hex Nut (1/8 IP)	1 pc.
R	Knurled Nut	1 pc.



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com


November 2011

3of8



STEP 1 - Install Fixture Loop

A. Thread the Fixture Loop (N) onto the nipple on the top center of the Fixture Body (P). Hand tighten until snug.



STEP 2 - Attach Crossbar to Outlet Box

A. Secure the Corssbar (A) to the outlet box with outlet box screws (not supplied). Tighten until snug.





Figure 2

STEP 3 - Attach Nipple to Crossbar

- A. Thread one Hex Nut (D) onto the top end of the Nipple (B).
- B. Place one Lock Washer (C) over the top end of the Nipple (B) and then thread the Nipple (B) into the center lock hole of the Crossbar (A).
- C. Using pliers, thread the hex Nut (D) against the Crossbar (A) and hand tighten until snug.



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com

© 2011 Quoizel Inc. November 2011


Q UOIZEL

6 CORPORATE PARKWAY
GOOSE CREEK, SC. 29445
www. quoizel. com

Assembly Instruction Sheet #IS-MCRU2820HA For Style MCRU2820HA


STEP 4 - Attach Canopy Chain Loop to Nipple

- A. Thread another Hex Nut (D) onto the end of the Nipple (B).
- B. Place the Lock Washer (C) over the end of the Nipple (B) and then thread the Canopy Chain Loop (E) onto the end of the Nipple (B).
- C. Using pliers, thread the Hex Nut (D) against the Canopy Chain Loop (E) and hand tighten until snug.




STEP 5 - Assemble Ceiling Canopy

A. Push the Ceiling Canopy (M) upward over the Outlet Box. Thread the Canopy Lock Ring (F) onto the Canopy Chain Loop (E) and tighten until snug to secure the Ceiling Canopy (M).



STEP 6 – Attach Fixture Chain to Canopy Chain Loop and Fixture Loop

- A. Adjust the Fixture Chain (G) to your desired length by removing the links if needed. You may need to use plier to open the chain links. If so, put a cloth over the chain to protect the finish from the pliers.
- B. Attach one end of the Fixture Chain (G) onto the Canopy Chain Loop (E) and then attach the other end of the Fixture Chain (G) onto the Fixture Loop (N) on the top of the fixture.



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700 or visit us on-line at www.quoizel.com

© 2011 Quoizel Inc.

QUOIZEL

Assembly Instruction Sheet #IS-MCRU2820HA For Style MCRU2820HA


Supply Wire and

Outlet Box

Ground Wire from

STEP 7 - Pass Supply Wires through Fixture Chain

A. Pull the Supply Wires and Ground Wire up through the Fixture Chain (G) alternating links. Push the wires up through the Canopy Chain Loop (E) into the outlet box.




Supply Wire and Ground Wire

Canopy Chain

Loop

STEP 8 - Make Wire Connections

- A. Un-thread the Canopy Lock Ring (F) and slide Canopy Lock Ring (F) and Ceiling Canopy (H) down the Fixture Chain (G).
- B. Push all slack fixture wire through Canopy Chain Loop (E) into Outlet Box. Trim excess fixture wire leaving a minimum of 6 inch. Hanging out of the Outlet Box.
- C. Use standard wire connectors to make all wire connections. (Connectors are not included with fixture.) Strip and prepare wire ends according to instructions supplied with connectors.




Thank you for purchasing a Quoizel product. Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700 or visit us on-line at www.quoizel.com © 2011 Quoizel Inc. November 2011




STEP 10 - Assemble Nipple with Hex Nut

A. Thread the short nipple end of Nipple with Hex Nut (H) into the Hex Coupling underside of the Fixture Body (P). Handtighten until snug.




STEP 11 - Attach Shade to Socket Assembly

A. Place Spacer Tube (I), Check Ring (J) over the end of the Nipple with Hex Nut (H) in turn. Secure by threading the Knurled Nut (R) onto the Nipple. Tighten until snug.



STEP 12 - Attach Shade to Socket Assembly

- a. Place the Shade (O) over the end of the Nipple. Secure by threading the Hex Nut (Q) onto the Nipple. Tighten until snug.
- b. Place the Cap (K) over the end of the Nipple. Threading the Finial (L) onto the Nipple. Tighten until snug.



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com


November 2011



STEP 12 - Install Bulb

- A. This fixture uses standard bulb with a standard screw base. Maximum 60 watts.
- B. Insert bulb and screw properly into place.

Your lamp semi-flush fixture is now assembled and ready to use. Enjoy!



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com