

ASSEMBLY INSTRUCTIONS FOR YOUR HOPE PENDANT

IMPORTANT SAFETY INSTRUCTIONS:

*These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.

***WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.**

*Turn off power at switch before replacing bulbs

*If any special control devices are used with this fixture, follow the instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a qualified electrical contractor.

*This fixture is UL rated for dry locations.

ASSEMBLY INSTRUCTIONS:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/ CIRCUIT BREAKER.
2. Remove all parts carefully from the carton. Do not throw away any parts.
3. Remove quick link (G) from hang straight (F). Keep quick link (G) attached to chain (H).
4. Remove cross bar (A) (with threaded tube (C) and hang straight (F) attached) from canopy (D). Do this by unthreading collar (E) from hang straight (F). Canopy (D) will slip over hang straight (F). Set the canopy (D) and collar (E) aside.
5. Affix cross bar (A) (with threaded tube (C) and hang straight (F) attached) to ceiling outlet box using screws (B) provided.
6. Measure desired drop for fixture to hang and add/remove chain links (H) with chain break tool (not included). Reattach quick link (G) to the top chain link (H).
7. Slip collar (E) over chain (H) so it rests on housing (I). Slip canopy (D) over chain (H) so it also rests on housing (I).
8. Lift fixture to ceiling and secure quick link (G) to hang straight (F). Guide wire through chain (H), through the center of the hang straight (F) and threaded tube (C).
9. Cut the cord to the desired length to make electrical connections. At least 8" of wire will be needed to make proper electrical connections.
10. Make proper electrical connections described in steps 11-13. A LICENSED ELECTRICIAN IS RECOMMENDED.
11. Attach ground wire from the fixture (green or copper in color) to the ground wire in outlet box. Fasten wires together with wire nut (P) and tightly wrap connection with electrical tape.
12. Attach hot wire from fixture (black in color, or smooth side of wire) to hot wire from ceiling outlet box. Fasten wires together with wire nut (P) and tightly wrap connection with electrical tape.
13. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from ceiling outlet box. Fasten wires together with wire nut (P) and tightly wrap connection with electrical tape.
14. Gently push wire connections back into ceiling outlet box. Slide canopy (D) up chain (H) and hold firmly against ceiling. Slide collar (E) up chain (H) and thread onto hang straight (F), securing canopy (D) against ceiling.
15. Install four 60 WATT MAX. Type B, medium base bulbs into sockets (O).
16. Carefully hang discs (N) onto bottom shade arms (M).
17. Repeat step 16 using remaining discs and working up one tier of shade arms (L, K, J) at a time until all arms have discs.
18. Reconnect main electrical supply from the fuse box/ circuit breaker and test the fixture.

To clean, use soft cloth only. Do not use any chemical or abrasive cleaners.

