
Robert Abbey, Inc. ASSEMBLY INSTRUCTIONS FOR YOUR

CRANE TABLE LAMP

IMPORTANT SAFETY INSTRUCTIONS:

- * For safety purposes, this lamp is equipped with a three prong plug. If the plug does not fit securely into outlet, do not force it - contact a professional electrician.
- * Use the plug with an extension cord ONLY if it can be fully inserted into the cord's socket. Never alter plug in any way.
- * This fixture has been rated for up to (1) 35W MAX. GY 6.35 BI-PIN 12V halogen bulb.
- * To avoid risk of fire, do not exceed recommended wattage.
- * Do not operate lamp without glass diffuser (A) installed.
- * This lamp is designed for indoor use only. High humidity or extreme temperatures will deteriorate the ballast.



ASSEMBLY INSTRUCTIONS:

- 1. REMOVE ALL PARTS CAREFULLY FROM CARTON.
- 2. Place base (E) on level surface.
- 3. To adjust position of lamp, carefully grasp shade guide (C) and move shade into desired position.
- 4. Insert three prong plug (F) into wall outlet.
- 5. When changing the location of the lamp, turn the lamp off at the switch and remove plug (F) from the wall outlet. Grasp column (D) with one hand and put the other hand under base (E) to support the weight of the lamp. Always place the lamp on a level surface

BULB REPLACEMENT

- 1. Make sure adequate time has been given for bulb to cool off after turning lamp off at switch.
- 2. Unplug lamp from wall outlet and remove diffuser (A) from shade by removing diffuser screws (B).
- 3. Remove old bulb by carefully pulling from the base and set aside.
- 4. Wrap new bulb with soft cloth when installing to refrain from touching bulb. Oil from skin will reduce the performance of the bulb and can cause it to burn out more quickly than normal.
- 5. Reattach diffuser (A) by aligning holes in diffuser (A) and holes in shade frame and inserting diffuser screws (B). DO NOT overtighten screws (B) as doing so can cause diffuser (A) to break.

NOTE: To clean, use a soft cloth only. Do not use chemical or abrasive cleaners.