



ASSEMBLY INSTRUCTIONS



Venezia Medium Faceted Scroll-Top Lantern Item # CHC 5262

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING***SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.



NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

1. Carefully remove all parts from the box.
2. Install the crossbar (B) with ceiling loop (D) to the ceiling junction box by mounting screws (C) provided.
3. With the fixture desired height, shorten the chain (G) as needed using a pair of chain pliers.
4. Open the one chain quick link, then attach the chain quick link to the top ring (H). Secure the chain quick link.
5. Let collar ring (G) and canopy (E) go through the chain (F).
6. Open the another chain quick link, then attach the chain quick link to the ceiling loop (D). Secure the chain quick link.
7. Remove the four flowers (J) from the cage door corners by loosening the screws (K).
8. Open the door (O) on the cage frame (M):
Step.1. Put the cluster (L) bottom up and three sockets into the open door.
Step.2. Turn the cluster (L) to bottom down in the cage slowly and carefully.
Step.3. Hang the cluster hook on the ring (I) in the cage.
9. Insert the glass panel (N) on then cage frame (M) and secure by bending the metal tabs.
10. Weave the fixture wire and the ground wire through the chain (F).
11. Feed the fixture wire and ground wire through the ceiling loop (D) and pull until taut. Measure the wires then cut. Be certain to leave enough length to connect inside of the ceiling junction box.
12. Strip the insulation back on the two power supply wires about 5/8".



VISUAL COMFORT & Co. Est. 1987

ASSEMBLY INSTRUCTIONS



Venezia Medium Faceted Scroll-Top Lantern Item # CHC 5262

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING***SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

13. Connect the fixture ground (bare) wire with the ground wire from the junction box using wire nut (A). If your house does not have ground wire, then attach this wire to the green grounding screw inside of the junction box.

IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED.

14. Connect the fixture Neutral wire (ribbed) with the neutral wire (White) from the junction box using wire nut (A).

15. Connect the fixture Hot (smooth, marks with words) wire with the hot wire (Black) from the junction box using wire nut (A).

DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.

16. Tuck these wire connections neatly into the outlet box to secure.

17. Put canopy (E) flush to the ceiling, and secure with collar ring (G).

18. Open the door (O) and insert bulbs (not included) into the sockets.

19. Close the door (O), then attach the four flowers (J) to the door corners and secure with screws (K).

20. Installation is complete, turn on power at fuse or circuit breaker.

***Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.



VISUAL COMFORT & Co. Est. 1987