


ASSEMBLY INSTRUCTIONS

Layton 10" Sconce

Item # CHD 2455

NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.



9. Loosen thumb screws **(E)** and insert top of shade **(G)**, then secure with thumb screws **(E)**.

NOTE: To ensure shade is level, thread each thumb screw an even amount until secure. Do not overtighten, otherwise shade could become damaged.

10. Insert light bulb into the socket.

Care Instructions: Clean only with a soft dry cloth or feather duster. Do not use abrasive or chemical agents.

