



## MODEL#: 1580-CH ASSEMBLY AND DRESSING INSTRUCTIONS


### IMPORTANT

TURN OFF THE POWER AT THE MAIN  
 FUSE OR CIRCUIT BREAKER BOX  
 BEFORE STARTING INSTALLATION




You will need 1-Med.BULB  
 40 watts Recommended  
 60 watts Max  
 Bulb not included

### For Hanging



### For Ceiling



A= (14mmX4pcs+20mmX4pcs)X5pcs

B= (14mmX4pcs+20mmX4pcs)X5pcs