

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER .

ASSEMBLING THE FIXTURE (Fig.2)

1. Return the arms to suitable position.
2. Attach the pipe screw (D) to the top coupling of the fixture body(E) and tighten it securely with the hex nut. Place the crown(C) over end of pipe screw(D) protruding fixture body, lock it securely with the finial(A). Attach the one end chain(B) to the arm's small ring of fixture body(E),close the link. Attach the other end chain(B) to the arm's hook of canopy.
3. Place the glass shade (G) onto the lamp holder of the fixture body (E) and lock it securely with the ring(F).
4. Raise the harp(J) to the bottom of screw protruding and lock it securely with the ball nut(I).Raise the light bulb(H 120V 7W) to the bottom socket of the fixture body(E),this is light bulb no included. Raise the glass(K) and cover(L) to the bottom of harp's pipe screw protruding and lock it securely with the finial(M).
5. Install the light bulbs(no including) in accordance with the fixture specifications. **NOTE: DO NOT EXCEED THE SPECIFIED WATTAGE!**

HANGING THE FIXTURE (Fig.1)

1. Shut off the power at the circuit breaker and remove old fixture from ceiling, including the old hardware.
2. Carefully unpack new fixture and lay all the parts on a clear surface.
3. Thread the two Studs(A) about 1/4" into the pre-drilled holes in the Mounting plate spaced the same distance apart as the holes in the canopy.
4. Attach the Mounting plate to the Junction Box with the two Junction Box Screws as shown. The side of the Mounting strap marked "GND" must face out.

CONNECTING THE WIRES (Fig.3)

1. Take the black wire from the ceiling junction box and the smooth wire leg from the fixture and twist bare ends together. Twist wire connector onto end of wire until snug.
2. Repeat same process with white junction box wire and ribbed wire leg of fixture wire. NOTE: Twist wires together in the same direction you twist the wire connector onto wires.
3. If your junction box has a grounding wire (green or bare copper), attach this wire and the bare copper wire from the fixture together as step 1.If junction box has no ground wire, attach the bare copper fixture wire to the green ground screw on the mounting plate.
4. Tuck these wire connections neatly into the ceiling outlet box and then raise the fixture canopy all the way to the ceiling.
5. Raise the canopy onto the junction box, aligning screws on mounting plate with mounting holes in canopy and lock it securely with the ball nuts. Attach the finial to the bottom end pipe screw of canopy by turning it clockwise until tight.

Your installation is now complete Return power to the junction box and test the fixture.

Fig.3




		
FIXTURE WIRES Black or Smooth	FIXTURE WIRES White or Ribbed	FIXTURE WIRES Bare Copper (Ground)
HOUSE WIRES Black (Hot)	HOUSE WIRES White (Neutral)	HOUSE WIRES Green or Bare Copper (Ground)

Fig.1




Fig.2

