

























Fixture Name: Accurian 7158-SF PW/RBZ

This fixture assembled PO: _____ Date: _____

Notice: Please review the parts listing and check for all parts before assembling the fixture. If any parts are missing or damaged, please note on this sheet and contact the place of purchase to arrange for replacement parts.

PARTS LIST		Company Name: _____ Co. Account #: _____ to be filled out by retailer	
Canopy 1ea @5"X1"		Wire connectors 5ea P3 Orange 	Top loop 1ea 80X38X26mm 
Chain 1ea 6ft x3.8mm		Junction Box Screw 2ea 8/32" x 1" 	Spring Washer 1ea Φ15X3mm 
Chain connector 2ea @4X55mm		Canopy Loop with Collar 1ea Φ23X42.4mm 	Nipple 1ea @3/8 x 45mm 
Mounting Strap w/ ground screw 1ea 100X20X4.5mm		Hex Nut 3ea @3/8 x 4mm 	Hex Nut 2ea 5/32 - 22NX2.5mm 
Mounting Strap w/ ground screw 1ea 102X76.2X3mm		Junction Box Screw 4ea 8/32"X1" 	Threaded rod 1ea 3/8"-27NX25mm 
Screws 2ea 5/32 - 22NX2.5mm		Deco Nut 2ea Φ11.6X10.8mm 	Top Cap 1ea Φ134.5X20mm 
Threaded Rod 1ea 3/8-27NX105mm		Flat washer 1ea Φ25X2mm 	Cap 1ea Φ52.4x5mm 
Bottom cap 1ea Φ59X9mm		Finial 1ea Φ13X15mm 	Hex Key 1ea 
Part Needed _____		Quantity _____	
Part Needed _____		Quantity _____	
Reason why _____	(missing, scratched, broken glass, bent, bad finish)		
Comments _____			


FIXTURE ASSEMBLY INSTRUCTIONS

Read and review installation instruction sheet before assembling the fixture.

ASSEMBLING THE FIXTURE AS SEMI-FINISH (Fig. 1)

1. Gently spread the arms until evenly spaced if arms are packed closed.
2. Thread the fixture Center column (D) into the housing nipple (E).
3. Slide the Decorative Rods(C') into the holes on Canopy(F) and tighten Screws(B') on the Arms(F') with Hex Key(A') (See Detail A-A')

NOTE: INSTALL THE GLASS ASSEMBLY AFTER THE FIXTURE IS HUNG.



For Customer Service, contact the place of purchase to arrange for replacement parts.

Fixture Name: Accurian 7158-SF PW/RBZ

WARNING ! SHUT OFF POWER AT FUSE OR CIRCUIT BREAKER.

HANGING THE FIXTURE as Semi-flush (Fig. 1)

1. Carefully remove the new fixture from the carton and the yellow bag that holds all your parts. Check that all parts are included as shown in the illustration and parts list.
2. Shut off power at the circuit breaker and remove the old fixture from ceiling, including the old mounting strap.
3. The Mounting Strap (B) contains several pairs of threaded holes, find the pair of holes that match the holes spacing in your Canopy (F) and thread the two Mounting Screws (A) into the Mounting Strap (B).
4. Place the Mounting Strap (B) over the Junction Box so the Mounting Screws (A) are vertical or horizontal, as required by fixture type.
5. Attach the Mounting Strap (B) to the Junction Box by using the two Mounting Screws (C). Tighten the screws securely with screw driver.

CONNECTING THE WIRES (Fig. 2)

6. Take the black wire from the ceiling junction box and the smooth wire leg from the fixture and twist bare ends together. Twist wire connector onto end of wires until snug.
 7. Repeat same process with white junction box wire and ribbed wire of fixture.
- NOTE: Twist wires together in the same direction you twist the wire connector onto wires.
8. If your junction box has a grounding wire (green or bare copper), attach this wire and the bare copper wire from the fixture together as in step 7. If junction box has no ground wire, attach the bare copper fixture wire to the junction box with a screw.
 9. Tuck these wire connections neatly into the Junction Box and then raise the Canopy (F) all the way to the ceiling and tighten with Deco Nuts (E).

FINISHING THE INSTALLATION (Fig. 3)

10. Place the fixture's Canopy (F) over the Mounting Strap (B) and over the Mounting Screws (A). Adjust the fixture canopy until the Mounting Screws (A) protrude out from the canopy. Secure the fixture against the ceiling by threading the Decorative Nuts (E) on until tight.
 11. Install the light bulbs and glass shade according to the fixture assembly sheet
- YOUR INSTALLATION IS NOW COMPLETE. RETURN POWER TO THE JUNCTION BOX AND TEST THE FIXTURE**

Fig. 1




Fig. 2





Fig. 3




WARNING ! SHUT OFF POWER AT FUSE OR CIRCUIT BREAKER.

HANGING THE FIXTURE (Fig. 1)

1. Carefully remove the new fixture from the carton and the yellow bag that holds all parts. Check that all parts are included as shown in the illustration and parts list.
2. Shut off the power at the circuit breaker and remove old fixture from ceiling, including the old mounting strap.
3. Thread Nipple (C) into Canopy Loop (F) until snug.
4. Thread other end of the Nipple (C) with Canopy Loop attached into Mounting Strap (D).
5. Place Lock Washer (B) over end of Nipple (C) protruding through Mounting Strap (D) and thread Hex Nuts (A) onto Nipple until tight.
6. Take this mounting strap assembly and mount to ceiling junction box with junction box Screws (E). Tighten screw securely with screw driver.
7. Unscrew the Canopy loop collar (H) from the Canopy loop. Take the canopy and pass over the Canopy loop. approximately one half of the canopy loop exterior threads should be exposed. Adjust until desired height is reached. *the Canopy loop collar should fit snugly on the Canopy loop after the canopy is installed. Remove Canopy and Canopy lock collar.
8. Assemble the fixture and have an assistant or secure support hold the weight of the fixture while you complete the wiring connections.
9. Thread the fixture wires and ground wire of the assembled fixture through the canopy loop and nipple and into the outlet box.


Fig. 1



CONNECTING THE WIRES (Fig. 2)

10. Attach the power supply wires to the fixture lead wires by connecting BLACK to BLACK (or SMOOTH) and WHITE to WHITE (or RIBBED).
 11. Attach the GROUND wire (GREEN or COPPER) from the Junction Box and the fixture Ground wire to the green Ground Screw on the Mounting Bracket (D) or connect both wires together using the correct size of wire connectors.
- NOTE:** Twist the wires together in the same direction you twist the wire connector onto the wires.
12. Tuck these wire connections neatly into the Junction Box.
 13. Raise Canopy (G) to the ceiling and secure in place by tightening the Canopy loop collar (H) into the Canopy Loop (F).
 14. Install the light bulbs and shade as per the fixture assembly sheet.

Fig. 2



**YOUR INSTALLATION IS NOW COMPLETE.
RETURN POWER TO THE JUNCTION BOX
AND TEST THE FIXTURE.**