


ASSEMBLY INSTRUCTIONS FOR YOUR BLAKE SCONCE



IMPORTANT SAFETY INSTRUCTIONS:

- * These instructions are provided for your safety. It's important that all instructions are read before beginning fixture installation.
- * We **STRONGLY** recommend installation by a licensed electrician.
- * Turn off power at switch before replacing bulbs, making sure fixture has had sufficient time to cool down.
- * Do not connect the electricity until lamp is fully assembled.

ASSEMBLY INSTRUCTIONS:

1. SHUT OFF MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
2. Remove mounting plate (D) from back plate (C) by removing screws (E). Set screws (E) aside.
3. Carefully pull the wiring from wall outlet box. Thread the wires through the center hole in mounting plate (D).
4. Affix mounting plate (D) to wall outlet box using mounting screws (F) provided.
5. Lift fixture to outlet box and make proper electrical connections described in steps 6 - 8. A licensed electrician is recommended.
6. Connect ground (green or silver in color) wire from fixture to ground wire in the outlet box. Fasten wires together with wire nut (G) and tightly wrap the connection with electrical tape.
7. Attach hot wire from fixture (black in color or smooth side of wire) to hot wire from outlet box. Fasten wires together with wire nut (G) and tightly wrap connection with electrical tape.
8. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from outlet box. Fasten wires together with wire nut (G) and tightly wrap connection with electrical tape. Carefully push wire connections back into wall outlet box.
9. Slide backplate (C) over mounting plate (D). Thread screws (E) into vacant holes at the top and bottom of backplate (A) to secure the fixture to the mounting surface.
10. Insert two (2) 60W MAX. Type B10.5 candelabra base bulbs into sockets. Slide glass shade (A) into the top of shade frame (B).
11. Reconnect main electrical supply from the fuse box/circuit breaker and test fixture.

** To clean, use a soft dry cloth. Do not use any chemical or abrasive cleaners as they may damage the finish. **